

# 2.4G+Bluetooth Three mode wireless keyboard











For better usage experience of the product, please read this manual before using it.

## **Product features:**

- 1. Support switching back and forth across devices
- 2. Three-system mode switching; the mainstream equipment of the general market
- 3.Bluetooth 3.0+ 5.0 is better compatible with new and old devices
- 4. Connect version 5.0 to hibernate and wake up faster
- 5. With high frequency equipment switching, the keyboard works smoothly

#### Connection Description: Note: FN key is the second key in the bottom left corner of the keyboard.

- 1. Turn the power switch to ON to turn on the keyboard
- 2.4G mode: (system default)

Take out the USB receiver and plug it into the computer

Bluetooth mode:

Press and hold FN, then press 1, and then press and hold for 3 seconds, the blue light flashes, and Bluetooth device 1 enters the searched state on the device side-open the system settings—turn on Bluetooth→search and add

#### Multi device connection:

- 1.FN +1: connect Bluetooth device 12.FN+
- connect Bluetooth device 23.FN+
- 3. connect USB, 2.4G wireless receiving
- 4.FN +1,2,3 combination single press: you can switch the paired devices
- 5.FN + 1,2, combined long press for 3 seconds: flashing light, can start the searched state (connect new equipment)

### **Connection supplement:**

- 1. The initial connection keyboard needs to switch the device to the corresponding system
- 2. If the system is not switched, the function key may not work normally!
- 3.The use distance of keyboard is 5-10m, and the distance is related to different equipment and environmental factors

## FN combination function key:

Connection switching		Multimedia buttons	
FN+1	Combined long press for 3 seconds,	FN+F1	Brightness+
FN+2	flashing light cansearch to add new device	FN+F2	Brightness-
FN+3	Switch to USB wireless	FN+F3	Show desktop
		FN+F4	screen capture
FN+Q	Android mode	FN+F5	Search
FN+W	Windows mode	FN+F6	Lock screen
FN+E	Apple IOS mode	FN+F7	The last song
FN+S	Windows, F1-F12	FN+F8	Play/Pause
		FN+F9	The next song
FN+1	Combined single press can switch paired devices	FN+F10	Mute
FN+2		FN+F11	Turn down the volume
FN+3		FN+F12	Turn up the volume

## Troubleshooting:

- 1. When the keyboard can't be searched, try Bluetooth on the switchdevice to search again
- 2. When the keyboard is turned on and there is no indicator light, try tocharge the keyboard
- 3. After connecting other devices, you need to delete the old records beforeconnecting back to the original devices
- 4. When the pairing fails, the failed pairing record needs to be deleted and the second pairing is performed

User information		
Uuser name:	Cortact phone:	
Mailing address:		
E-mail address :	*	
Produsi model:	Date of purchase:	